



1 Mitre box fabricated on job site to accommodate gutter in upright position.



2 Custom blade, available through Coastal Forrest Products: a conventional bow saw with a high-strength metal cutting blade.

3 Join using tape as clamps: stretch tape, pull seams together, lightly sand area to be bonded.

4 Using fiberglass mesh sheetrock or plaster seam tape, apply Bond & Fill or PVC Trim Welder. Let dry for appropriate time depending on temperature. Remove tape.



5 Install downspout.